

The right choice of your spray gun !

Application Recommendation

Wall Painting/Window Construction



Finding the right SATA spray gun for your material

| SATA LM 2000 B RP | SATA LM 2000 HVLP | SATA Spray Master | SATAjet B/GR | SATAjet RP | SATAjet 2000 HVLP | SATA Spray-Mix 1:32 | |
|-------------------|-------------------|-------------------|--------------|--------------|-------------------|---------------------|--|
| 2,0 | 2,1 | SM 0,3-0,8** | 2,0 | 2,0 | 2,2 | 2350 2850 | Rubbol Primer Rubbol Undercoat |
| 2-3 bar | 3 bar | 1,5-3 bar* | 3-4 bar | 1,5-2 bar | 2 bar | 3/3 bar* | |
| 2,0 2,5 | | SM 0,3-0,8** | 2,0- 2,5 | 2,0- 2,5 | 2,2 | 2850 | Rubbol Inside Filler L Rubbol Inside Filler S |
| 2-3 bar | | 1,5-3 bar* | 2-3 bar | 1,5-2 bar | 2 bar | 3/3 bar* | |
| 1,6- 2,0 | 1,9 | SM 0,3-0,8** | 1,7- 2,0 | 1,6- 2,0 | 1,7- 2,2 | 2350 2850 | Rubbol Azura Rubbol Satura |
| 2-3 bar | 3 bar | 1,5-3 bar* | 3-4 bar | 1,5-2 bar | 2 bar | 3/3 bar* | |
| 1,6- 1,8 | 1,7-1,9 | | 1,7- 2,0 | 1,6- 2,0 | 1,7- 1,9 | 2350 2850 | Rubbol BL Isoprimer |
| 2-3 bar | 3 bar | | 3-4 bar | 1,5-2 bar | 2 bar | 3/3* | |
| 1,6- 1,8 | 1,7-1,9 | | 1,7- 2,0 | 1,6- 2,0 | 1,7- 1,9 | 2350 2850 | Rubbol BL Azura Rubbol BL Satura Rubbol BL Satin |
| 2-3 bar | 3 bar | | 3-4 bar | 1,5-2 bar | 2 bar | 3/3* | |
| 1,6- 1,8 | 1,7-1,9 | | 1,7- 2,0 | 1,6- 2,0 | 1,7- 1,9 | 2350 2850 | Cetol BL Unitop |
| 2-3 bar | 3 bar | | 3-4 bar | 1,5-2 bar | 2 bar | 3/3 bar* | |
| | | SM 0,2-0,5** | | | | 2850 3350 | Cetol WF 750/755 Cetol WF 770 |
| | | 2-3 bar* | | | | 3/3* | |
| | | SM 0,3-0,8** | | | | 2850 3350 | Rubbol WF 368/370 |
| | | 2-3 bar* | | | | 3/3* | |
| | | | | | | | |
| | | | | | | | |

Please read the technical details of the recommended spray gun types in our operating manual on our website www.sata.de. E.&O.E. Technical alterations reserved. 4004-08

* Atomizing air/Pump pressure in bar
** Material pressure in bar



SATA Farbspritztechnik GmbH & Co. KG
Domertalstraße 20
70806 Kornwestheim
Germany
www.sata.de